Axicon 6000 series

PC based Barcode Verifiers





FEATURES/BENEFITS

- ISO/ANSI Verification Standards
- Traditional Verification Standards
- USB or Serial Connection
- · Mac OS X version available
- Symbology Auto-Discrimination
- Automatic Variable Aperture (4, 5, 6, 10 & 20 mil)
- · Scan Saving & Loading
- Static Reflectance Meter
- Display of X Dimension/Magnification
- Product Look-up Option
- · Individual Bar/Space Dimensional Analysis



PRODUCT SUMMARY

The Axicon 6000 series comprises CCD based verifier hardware and Application software, conforming to the latest ISO/ANSI print quality standards (ANSI x3.182, ISO/IEC15416-1). Our equipment has been independently tested and conforms to ISO/IEC15426-1.

The Axicon 6000 series is designed for all barcodes where a 4, 5, 6, 10 & 20 mil aperture is mandatory up to 72mm width including light margins. The simple to use design reduces user error and eliminates product damage whilst providing the highest level of accuracy achievable for verification.

Simply install the software on your computer, plug in the verifier and you can be confident that your barcodes are being checked to the highest standards.

Exclusive software upgrade features including .csv file saving and the additional ScanDB software (spreadsheet reporting function), Application Identifier (AI) Data Content Checker and Product Look-Up, can either be supplied as part of the package or as a field upgrade to the standard software.

The Axicon Verifier, when used in conjunction with the accurately produced calibration sheet, forms an integral part of your ISO 9000 quality control procedures.

Free software updates for life are downloadable from our website www.axicon.com, ensuring that the instrument will remain at the leading edge.

THE RANGE:

Axicon 6000: Standard Model (for details see Software Specifications)

Axicon 6015: includes *Product Look-up Option:* links the software to a database providing a description of the product that the barcode should relate to as well as the quality control information.

Al Checker: (UCC/EAN-128 and RSS): gives the user descriptions of the application identifiers used and then validates the information, checking for possible structure and content errors (e.g. date errors, check digit errors, incorrect field lengths etc.).

.csv File Saving:

enables verified data to be stored as a .csv file, enabling the user to analyze their results using Excel, Lotus or any similar spreadsheet program. The system can be set to record all data automatically if required.

SOFTWARE SPECIFICATIONS

(Latest software updates can always be downloaded free from www.axicon.com.)

Symbologies Verified: EAN.UCC SYMBOLOGIES: EAN-8, EAN-13 (with or without addons), ITF-14/Case Code, RSS (all symbologies),

UCC/EAN-128, UPC-A, UPC-E (with or without addons).

OTHER SYMBOLOGIES: Code 39, Code 93, Code 128, Codabar, ITF, MSI Plessey, Pharmacode (Laetus: optional extra).

AIAG, Belgian Pharmacode (MSI), Belgian Pharmacode (Unique), CIP 39, Coupon Codes (UK, USA, Euro), Code Application Standards:

Vignette, HIBC, ISBN/ISSN, Italian Pharmacode (IMH), LPPR, M&S, SISAC, Variable Measure Codes (Branded,

Instore, Australian).

Full ISO/ANSI Parameter Analysis (Rmin, Rmax, Global Threshold, Symbol Contrast, Min Edge Contrast, Modulation, Analysis Performed on Relevant Symbologies:

Defects, Decodability, Decode), Decodability per Symbol Character (to ISO standards), Average Bar Gain, Check Digit Validation, Control Characters and Structure Checking, Data Length, Nominal Bar Width Analysis (X Dimension), Print Contrast Measurement (PCS), Symbol Structure including Parity, Subsets & Start/Stop Characters, Light Margin

Validation, Wide to Narrow Ratio Display and Validation.

Diagnostic Windows: Details Results Window, Dimensional Analysis, Pass/Fail Window, Scan Reflectance Profile, Static Scan Reflectance,

Summary Window, Traditional Results Window.

Options: Application Identifier Data Content Checker (for UCC/EAN-128, RSS), Product-Look-Up Table.

Scan Saving and Loading - stores complete details of scan file data. Allows for remote diagnostics and also for Logging:

increased traceability.

A record of date and time to show when the hardware has been calibrated is kept - vital for ISO 9000 records. Calibration Logging:

Configurable Options: Audible Warnings, Calibration Expiry Period, Changeable Pass / Fail and Warning Colours, Check Digit Validation

(Code 39, Codabar, ITF), File Saving, Multi-Scan Averaging, Pass Grade, Print Options, Window Sizes and Positions.

Error Messages: Check Digit Error, Incorrect Wide to Narrow Ratio, Plugin Error, Print Quality Failure, Light Margin Error, Reference

Decode Algorithm Error, Structure Error, Unsuitable X Dimension.

Plugins available: Free: Code 39 full ASCII, Gen Spec, Job Reference, ext Lookup, Time Zone, UPC, User Data, User Name,

(see also Application Standards). Chargeable: Al Checker, CSV File Saving, Product Lookup.

Additional Software: Pharmacode (Laetus) - Decode and Analysis of Laetus Pharmacode.

ScanDB - Reporting Tool transferring data from saved scans into a .csv file.

HARDWARE SPECIFICATIONS:

Dimensions: 165 x 75 (50) x 55 mm, Scan Width - 72mm (including Light Margins)

Weiaht:

Construction: Black ABS plastic Interface:

Current Draw - 110mA. External power required for serial connection - PS2 cable (or optional AT/XT cable) supplied Power:

to take power from keyboard port. Regulated 5V PSU also available.

Nominal Measuring

Aperture:

4mil, 5mil, 6mil, 10mil and 20mil.

The software automatically identifies the symbology/nominal bar size (X dimension) and adjusts the aperture size

in order to comply with the symbology specifications and International Standards.

Wavelength of Light: 660 nanometers

GENERAL INFORMATION:

Print of Analysis: A printed report can be produced on any connected printer. Printouts can be produced for the main

verification information (including: Decoded Number, Time & Date, Number of Scans, Code Type, Average ISO/ANSI Grade, Average Bar Gain, Magnification, Check Character, Light Margins and

Grading Percentage Value).

Standard Accessories: Transit Case, USB Cable, Calibration Sheet, Start-up Guide, Software CD, Compliance Certificates.

System Requirements: PC running windows 95 or later.

ISO/ANSI verifier aperture size: X Dimension **Aperture** Typical Use

> 5mil Less than 13mil Non EAN.UCC Symbologies

10mil 13 to 25mil Small ITF-14 and all UCC/EAN-128 codes

20mil greater than 25mil Large ITF-14 codes

[For all UPC and EAN retail codes the EAN.UCC specification requires that a 6mil aperture should be used.]

All trademarks are acknowledged as belonging to their respective companies

Due to Axicon's continuing product improvement programs, specifications and features herein are subject to change without notice.

FOR MORE INFORMATION CONTACT:



taking care of your bar codes

ISIS integration 40 The Meades Dormansland Lingfield, Surrey RH7 6PZ 01324 835884 Fax. 01324 835884 www.isisintegration.com